

IMG WOOD GUIDE



Most of our products and components are based on laminated wood construction technology. Utilizing a process called Ultra-Sonic wood lamination creates strong frames and allows us to create graceful designs.

Environmental and consumer friendly glue and chemicals are used in the production process. We use light colored wood like beech with an attractive grain to make veneer and laminated parts. They are highly suitable for staining in various colors.



Wood

More colors than anyone in the industry


Wood parts and laminated bases can be delivered in a wide range of colors and finishes. From rich Espresso to natural and more contemporary colors. Please note that all colors are not available on all models and some special order circumstances may apply.



900 NATURE BEECH




901 OAK




902 WHITE OAK




903 LIGHT CHERRY




904 CHERRY



905 GOLDEN TEAK



908 DARK BROWN




909 MAHOGANY



911 ESPRESSO



912 BLACK



913 MATT BLACK

Wood Care

Most of our products and components are based on laminated wood construction technology. Utilizing a process called Ultra-Sonic wood lamination creates strong frames and allows us to create graceful designs.

Environmental and consumer friendly glue and chemicals are used in the production process. We use light colored wood like beech with an attractive grain to make veneer and laminated parts. They are highly suitable for staining in various colors

Most of our products include laminated wood bases. Make sure the furniture is properly assembly in accordance with the assembly instructions before use. Bolts, screws and knobs can loosen after an extended period. This can create damage to the frame and instability to the furniture. Therefore, it is important to check and tighten all bolts, screws and knobs periodically. IMG recommends you do this at least every four (4) months or as needed.

Do not use your furniture unless all bolts, screws and knobs are firmly secured. If parts are missing, broken, damaged or worn – stop use of the product until repairs are made with factory authorized parts only. Please refer to assembly instructions for further information.

Exposing furniture to sunlight or extreme sources of heat and cold may damage or fade the wood or the wood stain color.

Wood and frame surfaces require regular dusting. When cleaning is needed, use a dampened cloth followed by a dry cloth. Do not in any circumstance use strong detergents or abrasive cleaners.

Remove liquid spills or dirt immediately from the wood frame and mechanism parts.





www.imgcomfort.com

IMG AS

Postboks 251
N-6239 Sykkylven
Norway

Tel: + 47 70 27 10 40
Fax: + 47 70 27 10 41

E-mail: office@imgcomfort.com