



MAINTANANCE

Bolts, screws and knobs can loosen after an extended period. This can create damage to the frame and instability to the furniture. Therefore, it is important to check and tighten all bolts, screws and knobs periodically. IMG recommends you to do this at least every four (4) months or as needed.

IMG Relaxers are equipped with an advance mechanism that is made with many components, springs and moveable parts. Naturally, some sounds from the steel frame mechanism might occur. To avoid uncomfortable sounds you should tighten the screws regularly and use a few drops of oil or transparent grease on all screws and pivot points. Use penetration oil spray that is not too liquid to avoid leak/spill or transparent grease suitable for this kind of application. Please ask your retailer for more information.



PICTURE 1



PICTURE 2

SAFETY RULES



PS! Please be aware that irregular use might cause risk and squeeze danger!

- The back cover skirt must always be properly fastened with Velcro tape to avoid somebody's hands/fingers getting into the chairs mechanism from the chair's backside.
- Do not allow children to sit and play on or near the chair or to operate the mechanism. The footrest might fold out and the child could get injured.
- Keep hands and feet away from the mechanism. Only the chairs user should operate the mechanism.
- Always leave the chair in upright position with folded in footrest.
- Do not sit on the armrest.
- Never sit on the footrest. Do not use the chair or footrest as step ladder.
- Never lift/carry the chair by the back or the footrest. Lift the chair by grabbing under the chairs arms, base or backside.
- The chair can only be used by one person at a time.
- Armrest protection cover is recommended to use (for fabric cover).
- If parts are missing, broken, damaged or worn – stop use of the product until repairs are made, using factory authorized parts only.

Failure to follow these warnings could result in serious injury.

IMG
N O R W A Y

Postboks 163 N-6249 Ørskog - Norway
Tel. +47 70 27 10 40 Fax. +47 70 27 10 41
E-mail: office@imgcomfort.com
www.imgcomfort.com

IMG Recliner/ Relaxer Collection



ASSEMBLY AND USER GUIDE


IMG
N O R W A Y

Please read this information carefully before you assemble and use the chair.


ASSEMBLING

IMG Relaxers are delivered with separated back and seat. The back is ready for assembly. Please proceed with the following steps:


1. Place the chair on the floor




2. Remove the connection protectors on the back and the flanges/brackets protectors on the seat



3. Attach the back by sliding the connectors into the flanges/brackets on the back part of the seat. Press the back down until you hear "click". Please ensure that you don't tear the skirt cover or that the skirt cover gets squeezed between the back and the seat.




4. Use the Velcro tape to fasten the skirt cover onto the lower part of the chair (the cover goes from the back to the back rail frame).



USER INSTRUCTION

By using the handle located at the inside or outside of the right arm - the footrest can be unfolded and the back can be regulated into rest positions.

The glide/rocker function is locked as long as the footrest is unfolded.



Folded footrest (in) **Unfolded footrest (out)**

- The back is locked in upright position
- The glide/rocker function can be operated
- With 360 swing function
- You can adjust the neck and head support
- The back angle can be adjusted from upright to rest positions
- The glide/rocker function is locked when the footrest is unfolded (out)
- With 360 swing function
- You can adjust the neck and head support

The built-in footrest can be unfolded by pushing the handle placed inside of the right arm - towards the back. To fold in the footrest you should use your feet to press the footrest down towards the chair and move your bodyweight forward in the chair. Note: The handle must be in front position to fold in the footrest. If the chair is equipped with an outside handle please move the handle backward to unfold the built in footrest. To fold in the footrest you should use your feet to press the footrest down in combination with moving the handle forward.

Do not use shoes directly against the footrest. This might cause damage to the cover/upholstery. Do not sit on the armrests. Never lift/carry the chair by the back or the footrest. Lift the chair by grabbing under the chairs arms, base or backside. Two persons are recommended to lift/carry the chair.